

# PC23d | PC43d | PC43t

## USB-to-Serial Adapter Instructions

USB 转串行接口适配器安装说明

USB 轉序列配接器安裝說明

Instructions d'installation de l'adaptateur USB/série

Installationsanleitung für USB-Seriell-Adapter

Petunjuk Pemasangan Adapter USB-ke-Serial

Istruzioni per l'installazione dell'adattatore USB-seriale


USB 대 직렬 어댑터 설치 안내

Instruções de Instalação do Adaptador USB-para-Serial

Инструкции по установке адаптера с USB-порта на последовательный порт

Instrucciones para instalar USB al adaptador de serie

USB-Seri Bağlantı Noktası Adaptörü Kurulum Talimatları



For more information on using this accessory, see the *PC23 and PC43 Desktop Printer User Manual*.

有关使用本配件的详细信息，请参阅 PC23 和 PC43 桌面型打印机用户手册。

關於使用此配件的詳細資訊，請參閱 PC23 及 PC43 桌上型印表機使用者手冊。

Pour plus d'informations sur l'utilisation de cet accessoire, consultez le *manuel d'utilisation des imprimantes de bureau PC23 et PC43*.

Weitere Informationen über die Verwendung dieses Zubehörs entnehmen Sie bitte der *PC23- und PC43-Desktop-Druckeranleitung*.

Untuk informasi lebih lanjut mengenai penggunaan aksesoris ini, bacalah *PC23 and PC43 Desktop Printer User Manual*.

Per ulteriori informazioni sull'uso di questo accessorio, consultare il *manuale dell'utente della stampante desktop PC23 e PC43*.

본 부속품 사용법에 대한 자세한 내용은 PC23 및 PC43 데스크톱 프린터 사용 설명서를 참조하십시오.

Para obter mais informações, sobre o uso deste acessório, consulte o *Manual do Usuário da Impressora para Desktop PC23 e PC43*.

Дополнительная информация об использовании устройства приведена в *руководстве пользователя настольных принтеров PC23 и PC43*.

Para obtener más información sobre cómo usar este accesorio, consulte el *manual del usuario para la impresora de escritorio PC23 y PC43*.

Bu aksesuarın kullanımı hakkında daha fazla bilgi için, *PC23 and PC43 Desktop Printer User Manual*.



Worldwide Headquarters  
6001 36th Avenue West  
Everett, Washington 98203  
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2011 Intermec Technologies Corporation. All rights reserved.



PC23d, PC43d and PC43t USB-to-Serial Adapter Instructions



P/N 943-324-001